


Operating your G434 Chair


Seat Height Adjustment:

Rotate the lever on the left-hand side upwards. Increase or reduce the load on the seat. Release the lever to secure the seat height.




Seat and backrest tilt:

Rotate the lever on the right-hand side downwards. Shift the backrest into the desired position by increasing or reducing the load on it. Rotate the lever upwards to fix it in position.




Seat depth adjustment:

Press the button on the right-hand side of the seat shell then slide the seat into the desired position. Release the button to secure the seat position.




Backrest resistance:

Pull out the crank handle on the left lever. By turning the crank handle (+/-) it is possible to adapt the force of the synchronized mechanism to one's individual body weight.



Lumbar support:


Slide the lumbar support along the side tracks into the desired position.



Forward tilt:


Activation: Push in the lever on the right-hand side. Briefly press on the backrest and then release.

Deactivation: Pull out the lever on the right-hand side. Push back the backrest to where it clicks into position.




Armrest width adjustment:

Release the quick release lever under the armrest and slide the armrest into the desired position. Resecure the quick-release lever.




Armrest height adjustment:

Press the button on the side of the armrest and slide the armrest into the desired position. Release the button.




Armrest depth adjustment:

Slide the armrest pad forward or backwards – click into place.



Armrest rotation:

Rotate the armrest pad into the desired position – click into place.



orangebox